


110*130mm




Smart Diffuser 150ml
User Manual
Model: CSH-DIFF300

Diffuser Operation

- Remove the upper cover. (FIG 1)
- Connect the AC adaptor to the DC socket on the base. (FIG 2)
- Using the measuring cup, fill the water tank with tap water up to the max water level line.
 - Do not overfill or mist output may be low.
 - Do not use hot water.
 - Never fill in water during operation.
 - Drop essential oil into water tank vertically. (About 0.1ML-0.15ML per 100ML water) (FIG 3)
- Replace the upper cover onto the base. (FIG 4)
- Connect the AC adaptor to a power outlet.
- Right Side Button - Mist Button:
 - 1st Press: Turn On continuous mist on low level.
 - 2nd Press: Turn On continuous mist on high level.
 - 3rd Press: Turn off the mist. (FIG 5)
- Left Side Button - Light Button:
 - 1st Press: Soft rotating colour
 - 2nd Press: Freeze current colour
 - 3rd Press: Turn OFF. (FIG 6)
- The unit turns off automatically when the water level reaches its lower limit.




Attention

- The amount and intensity of mist produced will vary, but this is not unusual and should not be considered as a fault.
- Factors that affect this include water type, humidity, temperature, air currents.
- Auto power off when water runs out.
- Applies only 100% natural essential oil. If they contain chemical ingredients, flavors or impurities may cause damage to the product.
- Before replacing another essential oil, follow the maintenance part to clean the product.

Accidental Leakage

In the event of the unit being knocked over or tipped during usage, please follow the instructions as below:

- Uplift the unit and remove the cover.
- Pour out any remaining water out of the water tank.
- Shake the unit gently to drain any water inside the mechanism, and then allow drying for at least 24 hours.




Maintenance

After using 5-6 times, or for 3-5 days, please clean the product as below:

- Unplug the unit from power supply and remove the cover.
- Pour out any remaining water out from the "DRAIN SIDE" of the water tank.
- Add some warm water into tank and mix with neutral detergent, wash with a cleaning cloth.
- If you find any dirt in the air outlet, please remove the container cover and clean it.
- Never use other acids, enzymes or detergents, as this may risk poisonous gas to be created or cause malfunction.

Note: Be sure to use a mild detergent.



Safety & Warnings

- Do not attempt to transform, disassemble, or repair the product. If the product needs to be repaired, contact kogon.com.
- Do not damage the power cable in any way. Stop using the device if there is any damage to the power cord.
- Do not carry the device by the power cord.
- Do not use the device and power adapter in a wet area such as bathroom, dressing room, greenhouse, etc.
- Make sure the device is kept clean. After using the product drain the water out of the water tank, and use a cloth to wipe it clean.
- The essential oils utilised may cause staining if spilled. Clean immediately if spilled.
- Do not fill from the tap directly. Use the measuring cup to add water into the water tank.
- Don't let the spray nozzle spray directly on furniture, clothes or walls.
- Avoid placing the device in direct sun light, close to an air conditioner, fan or high temperature appliances.
- Install the unit on a flat level surface.
- Avoid placing the device near other electronics.
- Don't block the mist outlet.
- Only use clean tap water.
- Do not move the device while it is operating.
- Don't touch the product while your hands are wet, in order to avoid electricity shock.
- Place the product out of the reach of children and pets.

Troubleshooting


Issue	Solution
Will not switch on or switch off	<ul style="list-style-type: none"> Is there enough water in the tank? <ul style="list-style-type: none"> -Please add water to the tank Is the power cord connected properly? <ul style="list-style-type: none"> -Please disconnect, check cables and re-connect carefully.
No mist or abnormal mist	<ul style="list-style-type: none"> Not enough water? or too much water? <ul style="list-style-type: none"> -Please add suitable amount of water in the tank, water must never be filled over 150ML (MAX)line. Dirt on the atomization piece? <ul style="list-style-type: none"> -Please refer to maintenance instructions remove and re-install correctly, so mist can be released freely. Cover and inner cover are not installed properly? Dirt on the air suction port on the underside of the base? <ul style="list-style-type: none"> -If too much dust in the air suction port, the mist will be restricted to come out. Just clean it.
Water leakage from product	<ul style="list-style-type: none"> Cover and inner are not installed properly? <ul style="list-style-type: none"> -Remove and reinstall correctly, so mist can be released freely. Low temperature or high humidity? <ul style="list-style-type: none"> -Under these conditions, the mist may condense quickly into water droplets.

Specifications


Dimensions	Approx 100 x 140MM
Weight(excluding adaptor)	Approx 200g
Power: Input/Output	AC100-240V 50/60Hz DC24V 500mA
Length of cord	Approx 170CM
Power	Approx 11W
Tank Capacity	150ML
LED light	3pcs
Material	PP
Accessory	AC Adapter and manual
Working frequency	2.4MHz

App Connection Guide


Download Connect SmartHome from App Store or Google Play.




Register and log in:
Register a new account via mobile phone number or email, setting password as letters with number/password must longer than 6 letters and less than 20).




Click "Add Home" to create a customized operation system.



Then "Add device", select device type as "all", Choose "Air Purifier" or "Water Purifier" or "Humidifier". Click "Confirm" indicator rapidly blink, then enter your WiFi password. Wait till the circle 100% completed. Now you can name your diffuser and control it via APP.



APP Control Guide



Click Power to turn on/off both the light and the mist.

Click Spray to control mist. Spray Mode: Weak Mode & Strong Mode Spray Timer: ON/OFF/30/60/90

Click Light to control light. Gradient Light color will cycle automatically. Fixed: Fix one color and brightness adjustable. Nightlight: Fix at green light and brightness adjustable.

Click Schedule to set mist or light schedules.

Note & QA

Note

- In order to pairing successfully, it's better to operate near the WIFI router. If your home Wi-Fi does not require a password, leave it blank.
- The device only supports 2.4GHz networks. 5GHz network is unavailable.
- If Failed to Add, please unplug the diffuser for 2 minutes and try again.

QA

Q: Router can not access the Internet, does it support the local area network? Can it directly connect to cellphones hot spots?
A: The Android version supports LAN control, while Apple version currently not. The device must be connected to the Internet via a router to communicate with the mobile server.

Q: Why can not I get a registered SMS verification code? Why can not mobile phone connect device hotspot?
A: Permission is limited. Select "Allow" when you encounter authorization during installation.


Q: My router is 5GHz, but the diffuser only work with 2.4GHz, can I connect with this diffuser?
A: Yes, some routers will run dual band by default - both 5.0GHz and 2.4GHz.

In this case, there are two steps you need to do as follows:
- Disable 5.0 GHz frequency (temporarily)
- Set up a guest network
After doing both these things, the device will pair correctly and you can re-enable the 5.0GHz frequency without any other influence.

Amazon Echo Connection

Compatible with Amazon Echo

- Download and install Alexa app.
- Register an Alexa account and pair your Echo.
- Add TuyaSmart skill.



Click menu at the upper left corner. Click Skills to enter skill store. Search TuyaSmart. Click Profile and Settings. Click Integration. Choose amazon alexa.

Follow the steps to connect with Alexa.

Step 1: Add Device
Make sure there is at least 1 device that is supported by Amazon Alexa. This is shown on the Integration Screen.

Step 2: Modify Device Name
Modify device name so your Amazon Alexa can easily recognize the name. For Example: Living Room Lamp, Bedroom Light.

Step 3: Set Up Alexa
Use Alexa App or Computer (<http://alexa.amazon.com>) to set up your Amazon Alexa.

Step 4: Add Skill
In the menu bar, go to "Skills" and search for "Tuya Smart". Enable Skill, then type in your login info from your app account to finish the account linking.

Step 5: Control Device
Ask Alexa to discover devices. After 20 seconds, devices will be discovered and Alexa will tell you "I found x devices". Then you can control your devices using voice through your Amazon Alexa product.

After completing, enjoy your smart home journey.
Or, you can search devices by the following orderings:
* Alexa, discover my smart home devices.
* Alexa, discover device.
* Alexa find device
After 20 seconds, echo will tell you how many devices it found.
Sign in Alexa app and click Smart Home to control the devices it found.

Operational Orderings.

(Make sure device name is English and don't use special characters that device cannot recognize.
Such as: My lamp, Switch, My switch, etc.)

Searching Devices:
*Alexa, discover my smart home devices"

Device On/Off Orderings:
*Alexa, turn on diffuser"
*Alexa, turn off diffuser"

Color Setting:
*Alexa, turn diffuser to red (white, green, yellow, blue, purple, orange)"

Percentage Setting - LED Brightness Adjustment:
*Alexa, set diffuser to 10 (20, 30, 40, 50, ... percent)"

WARRANTY AGAINST DEFECTS

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase.

How to make a product warranty claim:
Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.
Step 2a) Contact your place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
Step 2b) If your place of purchase cannot be contacted, then you can contact Laser Customer Service with details of your defective Laser Product: Phone: (02) 9670 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113
Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.
Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.