


CONNECT
SmartHome

Quick Start Guide

OUTDOOR SMART SECURITY CAMERA




Model: CSH-ODCAM

Welcome

Thank you for choosing our security camera.
Getting started is easy.


What's Included




Security Camera




Antenna



Alignment Sticker




Power Adapter



Wall Mount Screw Sets




Tight Line
Waterproof Kit




Quick Start Guide

Product Details



1. Connection Preparation


Make sure that the security camera and phone are within range of your router.



Camera



Router



Smartphone

Note: Make sure your smart phone is connected with your wireless router.

Please note the camera is only working under 2.4G Wi-Fi and does not support 5G Wi-Fi.

2. Download the App and create an account


For the best experience, please download the "Connect Smarthome" APP to your smartphone from App Store or Google Play, or you can also scan the QR code below, the APP icon will be displayed after installed successfully.




3. Insert the Micro SD card (optional)

- Unscrew these two screws at the back of the camera;

Unscrew these screws




- ② Take away the cover and insert the SD card gently.
Restore the cover with screws for waterproof.





4. Connect the power to the camera


Connect the power to the camera by DC12V/1A Power Adapter.



5. Set up your camera

- ① Press the Reset button from the tight line cable for about 5 seconds, then release the button, the camera will reset.
- ② Launch the app from your smartphone and click the Sign Up button. Follow the on-screen instructions.
- ③ Click "Add Device" or "+" on the right corner to add device; Then click" Security&Sensor" to select" Smart Camera"
- ④ Click the button to confirm if the indicator is red and blinking quickly, then input the correct working wifi password to proceed
- ⑤ Point the QR code to the camera lens for 15-20cm ; When the indicator turns to blue and blink quickly, click for next step. If failed, please reset and go back to start again






6. Place or Mount Your Camera


You can place your camera on a shelf or other flat surface, or you can mount it to the wall.

To mount your camera to the wall:

- Fasten the mounting screw into the wall, and then mount the camera from the screw.
- If you're mounting the camera to drywall, be sure the plastic drywall anchors that are provided.





Mounting on Wall



Mounting on Ceiling

You're done!

Congratulations! Your camera is set up and ready to go.



RoHS



E4651

All trademarks are used for reference purposes only.

Thanks again for choosing our security camera!

WARRANTY AGAINST DEFECTS

Laser Corporation Pty Ltd (“Laser”) warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage.

Please retain your receipt as proof of purchase

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser.

Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on “Consumers (End Users)”). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.