





MOTION SENSOR INSTRUCTION

CSH-MOSENSOR
CSH-MAGMOSENS



Product configuration



Wifi mode & AP mode

- (1) Hold the reset button for 6 seconds, the indicator will flash rapidly. Then device will be in smart Wi-Fi mode.
- (2) Hold the reset button again for 6 seconds, the indicator will flash slowly. The device will be in AP mode.

Specifications

- Battery: CR123A-3V X 1
- Standby current: 26uA
- Alarm current: 120mA-130mA
- Standby time: 5 years
- Battery Life: 2500 times trigger(1 year if trigger 7 times per day, 2 years if trigger 3 times per day)
- Wireless type: 2.4GHz
- Wireless standard: IEEE 802.11b/g/n
- Wireless range: 45M
- Sensitive distance: 4-6M
- Operating Temperature: 0 C ~ 40 C (32°F ~ 104°F)
- Operating Humidity: 20% ~ 85%
- Storage Temperature: 0 C ~ 60 C (32°F ~ 140°F)
- Storage Humidity: 0% ~ 90%
- Size: 50mm x 48mm x 48mm


Download App

1. Android phone: Download "Connect SmartHome" from Google Play Store
2. IOS device: Download "Connect SmartHome" from APP store.




Register and login

1. Run "Connect SmartHome" from your smartphone.
2. Register and login




Add Home

- Click "Add Home" to add a home.




- "Add device", select device types as "all", choose "Security & Sensor", Click "Sensor (Wi-Fi)". Confirm indicator rapidly blink"
- Then enter your Wi-Fi password. Wait till the circle reach 100%. When it shows "Device added successfully", you can name your alarm and control it via APP.




Main function

1. Status: Alarmed | Normal
- It takes 3-5 seconds to receive the notification pushing when triggered.




2. Alarm history
3. Notification: click "NOTICE" to change the notifications on pushed to your phone.




Alarm recording Silence notifications

4. Scenes
- Set scenes automate conditions (e.g. alarm trigger when your door is opened)




Device Sharing

Allow others to control the device by sharing device (note: you can delete the sharing in profile setting)




Push Notification

Enable or disable notifications



Remove device

You can click the top right corner to enter the settings and remove the device.



LED State

Device Status	LED State
Smart Wi-Fi	Indicator flashes quickly
AP mode	Indicator flashes slowly
Triggered	LED will rapidly blink, and OFF after scheduled time
suspend mode	Indicator off
Reset	Indicator lights up for 4s and after 2 seconds lights off, device goes into configuration mode

WARRANTY AGAINST DEFECTS

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product. Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Step 5: For further details on warranty cover and returns, please check Terms and Conditions for Warranty Returns section on www.laserco.com.au/warranty

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.